

IBD192 Series Dual Gigabit LAN CARD Mini PCI Express Card V1.2

User guide 1.0



Features:

- Form factor: Mini PCI-E interface.
- Compliant with IEEE 802.3 Ethernet interface for 1000 Base-T, 100 Base-TX and 10 Base-T applications (802.3, 802.3u, 802.3ud).

IBD192: Mini PCI-E LAN card with Intel I210-AT/I211-AT Ethernet controller, dual port; used with IBLD170D RJ45 card.

IBLD170D: Card with transformer + RJ45 for LAN ports (includes 2PCS EXT-484 cables).


IBD192 Connectors pin definition

CN1, CN2: LAN Connector

2X10_1.0mm_Straight_Male_Wafer (HIROSE DF20G-20DP-1V(56),
Mating connector: HIROSE DF20A-20DS-1C

	Signal Name	Pin #	Pin #	Signal Name
	MDI_0N	2	1	MDI_0P
	Ground	4	3	Ground
	MDI_1N	6	5	MDI_1P
	CT	8	7	Ground
	MDI_2N	10	9	MDI_2P
	MDI_3N	12	11	MDI_3P
	Ground	14	13	Ground
	LED_LINK1000	16	15	LED_LINK100
	LED_ACTIVITY	18	17	LED_LINK_UP
	NC	20	19	NC

IBD192 series and EXT-484 Mechanical Drawing



IBD192 x1 and EXT-484 x2

Mini PCI-E LAN Card Driver Installation

Follow these steps to install the Intel I210/I211 LAN/Ethernet driver for Windows 7/8 / 8.1:

1. Insert the DVD that comes with the motherboard. Click **LAN Card** and then **Intel LAN Controller Drivers**.



2. Click **Intel(R) I21x Gigabit Network Drivers**.



3. Click **Install Drivers and Software**.



4. When the Welcome screen appears, click **Next**.
5. Click **Next** to agree with the license agreement.
6. Click the checkbox for **Drivers** in the Setup Options screen to select it and click **Next** to continue.
7. The wizard is ready to begin installation. Click **Install** to begin the installation.
8. When Install Shield Wizard is complete, click **Finish**.